






16190 antine (x3)



16190



utensili necessari
outils nécessaires
tools required



16190 A+B





16190 (A)


NOTES



1



2




3




AEx24

(7) x6 pcs


4



5






6





7


16190



8




PA



16190 antine (x3)



16190



16190 antine (x3)

16190

utensili necessari
outils nécessaires
tools required



CC



6

DA




6

QL



3

QM




3

VJ



12

VA



6

VZ




12

SB



3




NOTES



Instructions






1



8 x3 pcs

2






16190

(IT) Le ante possono andare in qualsiasi spazio

(FR) Les portes peuvent aller à tout espace

(EN) The doors can go to any space

3



16190 antine (x3)

16190